

230V 3000W Garden Vacuum, Blower & Mulcher

Stock No.82104 Part No.BV3000

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY TO ENSURE THE SAFE AND EFFECTIVE USE OF THIS PRODUCT.



DRAPER

CE

GENERAL INFORMATION

olicy of continuous improvement determines the right to make modifications without prior warning.

hese instructions accompanying the product are the original instructions. This document is part of the product, keep it or the life of the product passing it on to any subsequent holder of the product. Read all these instructions before ssembling, operating or maintaining this product.

his manual has been compiled by Draper Tools describing the purpose for which the product has been designed, and ontains all the necessary information to ensure its correct and safe use. By following all the general safety instructions ontained in this manual, it will ensure both product and operator safety, together with longer life of the product itself. If photographs and drawings in this manual are supplied by Draper Tools to help illustrate the operation of the product. Whilst every effort has been made to ensure the accuracy of information contained in this manual, the Draper Tools

TITLE PAGE

1.1 INTRODUCTION:

USER MANUAL FOR:

230V 3000W GARDEN VACUUM, BLOWER & MULCHER

Stock no. 82104 Part no. BV3000

1.2 REVISIONS:

Date first published May 2015.					

As our user manuals are continually updated, users should make sure that they use the very latest version.

Downloads are available from: http://www.drapertools.com/b2c/b2cmanuals.pgm

DRAPER TOOLS LIMITED WEBSITE: drapertools.com

HURSLEY ROAD PRODUCT HELPLINE: +44 (0) 23 8049 4344
CHANDLER'S FORD GENERAL FAX: +44 (0) 23 8026 0784

CHANDLER'S FORD GENERAL FAX: EASTLEIGH

HAMPSHIRE SO53 1YF

UK

1.3 UNDERSTANDING THIS MANUALS SAFETY CONTENT:

WARNING! Information that draws attention to the risk of injury or death.

CAUTION! Information that draws attention to the risk of damage to the product or

surroundings.

NOTE! Important information.

1.4 COPYRIGHT © NOTICE:

Copyright © Draper Tools Limited.

Permission is granted to reproduce this publication for personal & educational use only.

Commercial copying, redistribution, hiring or lending is prohibited.

No part of this publication may be stored in a retrieval system or transmitted in any other form or means without written permission from Draper Tools Limited.

In all cases this copyright notice must remain intact.

2. CONTENTS

2.1 CONTENTS

	PAGE C	ONTENT	PAGE
	TITLE PAG	iE	
	1.1	INTRODUCTION	. 2
	1.2	REVISION HISTORY	
	1.3	UNDERSTANDING THIS MANUAL	
	1.4	COPYRIGHT NOTICE	. 2
<u> </u>	CONTENT		_
	2.1	CONTENTS	. 3
3	GUARANT		
	3.1	GUARANTEE	. 4
ļ	INTRODU		_
	4.1	SCOPE	
	4.2 4.3	SPECIFICATIONHANDLING & STORAGE	
		SAFETY INFORMATION	. 3
)	5.1	GENERAL SAFETY INSTRUCTIONS FOR GARDEN TOOL USE	6
	5.2	GARDEN BLOWER/VACUUM SAFETY WARNING	
	5.3	CONNECTION TO THE POWER SUPPLY	
	TECHNICA	AL DESCRIPTION	
	6.1	IDENTIFICATION	9
,	UNPACKI	NG & CHECKING	
	7.1	PACKAGING	.10
3.	PREPARIN	G THE BLOWER VAC	
	8.1	ASSEMBLING THE CHUTE	.11
	8.2	FITTING THE COLLECTION BAG	
	8.3	SHOULDER STRAP	
	8.4	ON/OFF SWITCH	. 13
	8.5	BLOWER/VACUUM FUNCTION	
	8.6 8.7	SPEED FUNCTION	
·.	TROUBLESHOOTING		. 15
0.	MAINTEN.	ANCE IAINTENANCE & PARTS REPLACEMENT	16
1			. 10
1.	DISPOSAL 11.1	DISPOSAL	17
2.		TION OF SYMBOLS	. 17
۷.	12.1	EXPLANATION OF SYMBOLS	18
NECL A		F CONFORMITYENCLOS	
	ANA HON O	F CONFORMITTENCLOS	ピレ

3. GUARANTEE

3.1 GUARANTEE

Draper tools have been carefully tested and inspected before shipment and are guaranteed to be free from defective materials and workmanship.

Should the tool develop a fault, please return the complete tool to your nearest distributor or contact Draper Tools Limited, Chandler's Ford, Eastleigh, Hampshire, SO53 1YF. England. Telephone Sales Desk: (023) 8049 4333 or Product Helpline (023) 8049 4344.

A proof of purchase must be provided with the tool.

If upon inspection it is found that the fault occurring is due to defective materials or workmanship, repairs will be carried out free of charge. This guarantee period covering parts/labour is 12 months from the date of purchase except where tools are hired out when the guarantee period is ninety days from the date of purchase. The guarantee is extended to 24 months for parts only. This guarantee does not apply to normal wear and tear, nor does it cover any damage caused by misuse, careless or unsafe handling, alterations, accidents, or repairs attempted or made by any personnel other than the authorised Draper warranty repair agent.

Note: If the tool is found not to be within the terms of warranty, repairs and carriage charges will be quoted and made accordingly.

This guarantee applies in lieu of any other guarantee expressed or implied and variations of its terms are not authorised.

Your Draper guarantee is not effective unless you can produce upon request a dated receipt or invoice to verify your proof of purchase within the guarantee period.

Please note that this guarantee is an additional benefit and does not affect your statutory rights.

Draper Tools Limited.

INTRODUCTION

1.1 SCOPE

his machine is designed to blow and vacuum leaves and other light debris.

1.2 SPECIFICATION

tock no	
Part no	BV3000
Rated voltage	230V/50Hz
Rated input	3,000W
Air flow speed (Blowing)	
Mulching ratio	up to 10:1
ollection bag capacity	35 ltr
ound pressure level	
ound power level	100.1dB(A) K=2.03dB(A) LwA=102dB(A)
/ibration level	
Veight (machine only)	3.0kg
ALWAYS WEAR APPROVED EAR AND EYE PROTECTION	

A-Weighted sound power level in accordance to 2000/14/EC

1.3 HANDLING & STORAGE

Always lift the machine by its purpose designed handle. Ensure you have a good stable position whilst using this product. Care should be exercised when using this product due to otating parts etc.

tore the product together with this manual in a cool dry place.

This product should be cleaned and maintained regularly to ensure it is operating at peak performance.

5.1 GENERAL SAFETY INSTRUCTIONS FOR GARDEN TOOL USE

WARNING: Read all safety warnings and all instructions. Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.

Save all warnings and instructions for future reference.

The term "power tool" in the warnings refers to your mains operated (corded) power tool or battery-operated (cordless) power tool.

- 1) Work area safety
 - a) Keep work area clean and well lit. Cluttered or dark areas invite accidents.
 - b) Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes.
 - c) Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.
- 2) Electrical safety
 - a) Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools. Unmodified plugs and matching outlets will reduce risk of electric shock.
 - b) Avoid body contact with earthed or grounded surfaces such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.
 - c) Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
 - d) Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of electric shock.
 - e) When operating a power tool outdoors, use an extension cord suitable for outdoor use. Use of a cord suitable for outdoor use reduces the risk of electric shock.
 - f) If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply. Use of an RCD reduces the risk of electric shock.
- 3) Personal safety
 - a) Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating power tools may result in serious personal injury.
 - b) Use personal protective equipment. Always wear eye protection. Protective equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.
 - c) Prevent unintentional starting. Ensure the switch is in the off position before connecting to power source and/or battery pack, picking up or carrying the tool. Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.
 - d) Remove any adjusting key or wrench before turning the power tool on. A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
 - e) Do not overreach. Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.
 - f) Dress properly. Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts.

HEALTH & SAFETY INFORMATION

- g) If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used. Use of these devices can reduce dust-related hazards.
-) Power tool use and care
 - a) Do not force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.
 - b) Do not use the power tool if the switch does not turn it on and off. Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
 - c) Disconnect the plug from the power source and/or battery pack from the power tool before making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.
 - d) Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users.
 - e) Maintain power tools. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.
 - f) Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
 - g) Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation.
 - Service
 - a) Have your power tool serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is maintained.

GARDEN BLOWER/VACUUM SAFETY WARNING

- Training:
 - a) Read the instructions carefully. Be familiar with the proper use of the appliance.
 - b) Never allow children to use the appliance.
 - c) Never allow people unfamiliar with the instructions to use the appliance. Local regulations may restrict the age of the operator.
 - d) Never operate the appliance while people, especially children or pets are nearby.
 - e) The operator or user is responsible for accidents or hazards occurring to other people or their property.
- Preparation:
 - a) While operating the appliance, always wear substantial footwear and long trousers.
 - b) Do not wear loose clothing or jewellery that can be drawn into the air inlet. Keep long hair away from the air inlets.
 - c) Wear protective goggles while operating.
 - d) To prevent dust irritation, the wearing of a face mask is recommended.
 - e) Before using, check the supply and extension cord for signs of damage and aging. Do not use the appliance if the cord is damaged or worn.
 - f) Never operate the appliance with defective guards or shields, or without safety devices, for example debris collector in place

5. HEALTH & SAFETY INFORMATION

g) Only use a weather proof extension cable fitted with a coupler according to IEC 60320-2-3.

3. Operation:

- a) Always direct the cable to the rear away from the appliance.
- b) If a cord becomes damaged during use, disconnect the supply cord from the mains immediately.

DO NOT TOUCH THE CORD BEFORE DISCONNECTING THE SUPPLY.

- c) Do not carry the appliance by the cable.
- d) Disconnect the appliance from the mains supply:
 - Whenever you leave the machine
 - Before cleaning a blockage.
 - Before checking, cleaning or working on the appliance.
 - If the appliance starts to vibrate abnormally.
- e) Operate the appliance only in daylight or in good artificial light.
- f) Do not overreach and keep your balance at all times.
- g) Always be sure of your footing on slopes.
- h) Walk, never run.
- i) Keep all cooling air inlets clear of debris.
- j) Never blow debris in the direction of bystanders.

4. Maintenance & Storage:

- a) Keep all nuts, bolts and screws tight to be sure the appliance is in safe working condition.
- b) Check the debris collector frequently.
- c) Replace worn or damaged parts.
- d) Use only genuine replacement parts and accessories.
- e) Store the appliance only in a dry place.

5.3 CONNECTION TO THE POWER SUPPLY

Make sure the power supply information on the machine's rating plate are compatible with the power supply you intend to connect it to.

This product comes supplied with a UK standard 3 pin plug fitted. It is designed for connection to a domestic power supply rated at 230V AC.

It is a Class 2 machine (double insulated); is designed for connection to a power supply matching that detailed on the rating label and compatible with the plug fitted.

If an extension lead is required, use an approved and compatible lead rated for this appliance. Follow all the instruction supplied with the extension lead.

This product requires no earth connection as supplementary insulation is applied to the basic insulation to protect against electric shock in the event of failure of the basic insulation.

Apart from replacing the fuse in the plug, no other electrical work is recommended on this product.

TECHNICAL DESCRIPTION



- ① Chute.
- Shoulder strap.
- Rear handle.
- Speed function.
- On/Off switch.

- Moulded plug and cable.
- 7 Blower/vacuum function control.
- 8 Collection bag
- Support wheels.

7. UNPACKING & CHECKING

7.1 PACKAGING

Carefully remove the blower/vac from the packaging and examine it for any sign of damage that may have happened during shipping. Lay the contents out and check them against the parts shown and those listed on page 9. If any part is damaged or missing; please contact the Draper Helpline (the telephone number appears on the Title page) and do not attempt to use the blower/vac.

The packaging material should be retained at least during the guarantee period: in case the machine needs to be returned for repair.

Warning! Some of the packaging materials used may be harmful to children. Do not leave any of these materials in the reach of children.

If any of the packaging is to be thrown away, make sure they are disposed of correctly; according to local regulations.

PREPARING THE BLOWER VAC

NOTE: Remove the plug from the socket before carrying out adjustment, servicing or maintenance.

MPORTANT:


Remove the label which sits in front of the impeller and assemble and fix chute BEFORE operating this blower rac.


3.1 ASSEMBLING THE CHUTE

Connect the two sections of the chute together and fix vith screw supplied (Figs.1-2).

it the chute assembly to the motor housing using the other screw (Fig.3).

Attach wheels once fully assembled (Fig.4).










8. PREPARING THE BLOWER VAC

NOTE: Remove the plug from the socket before carrying out adjustment, servicing or maintenance.

8.2 FITTING THE COLLECTION BAG

Push the two side lugs (Fig.5) into the slots in the housing so they click into place.

Ensure the collection bag port is securely fitted and bag clipped to chute (Fig.6).





8.3 SHOULDER STRAP

To aid with maneuverability and weight, the garden blower/vacuum comes supplied with an adjustable shoulder strap.

Connect strap to pivot point (Fig.7).

Adjust strap length to suit user height/preference.




PREPARING THE BLOWER VAC

3.4 ON/OFF SWITCH

o activate the garden blower/vacuum, fully press and hold the trigger (Fig.8).

o deactivate the garden blower/vacuum, simply release he trigger.

NOTE: This appliance should be supplied via a residual current device (RCD) with a tripping current of not more han 30mA.



3.5 BLOWER/VACUUM FUNCTION

To interchange between the blower/vacuum functions adjust control lever (Fig.9).

Lower adjustment control lever in to the position marked $\stackrel{\longleftarrow}{=}$ for the blower position.

Raise adjustment control lever in to position marked [1] for the vacuum function.

NOTE: Mulching action is automatic when in vacuum node and can reduce leaf volume by up to 10:1.



3.6 SPEED FUNCTION

o increase the power of the function, adjust the wheel o the desired speed.



8. PREPARING THE BLOWER VAC

8.7 COLLECTION

As the organic material is vacuumed up the chute it passes through an impellor which in turn reduces the volume as it loosely mulches the matter. When the collection bag is nearing capacity, stop the machine and disconnect the power supply.

Press the two release tabs inwards and pull the plastic collar forwards to remove from machine.

NOTE: Follow the procedure on page 8 for fitting the collection bag.

With the bag removed the collected organic material can be emptied for compost/recycling by opening the zip.

NOTE: Ensure the zip is completely closed prior to refitting the collection bag.

. TROUBLESHOOTING

TROUBLE	PROBABLE CAUSE	REMEDY	
Machine fails to operate	 Not plugged in. Fuse blown. RCD Tripped. Cable damaged. 	 Plug in and switch on. Replace fuse with fuse of the same amperage rating. Also check fuse in extension lead plug if applicable. Reset RCD. If problem occurs again, unplug the machine and have the machine checked by a qualified person. Do not use the machine until the cable has been replaced. 	
Poor suction, mulching or collection	 Collection bag full. Collection chute blocked. Impeller damaged. Collection bag damaged or open. 	 Unplug the machine and empty the bag. Unplug the machine and unblock chute. Have the impeller replaced by a qualified service agent. Close, refit or replace collection bag. 	
Reduced blower air flow	1. Blower chute blocked.	Unplug the machine and check for blockage.	

10. MAINTENANCE

10.1 MAINTENANCE & PARTS REPLACEMENT

Remove the plug from the socket before carrying out adjustment, servicing or maintenance. Regular inspection and cleaning reduces the necessity for maintenance operations and will keep your tool in good working condition.

The motor must be correctly ventilated during tool operation. For this reason avoid blocking the air inlets.

If the replacement of the supply cord is necessary, this has to be done by the manufacturer or his agent in order to avoid a safety hazard.

DISPOSAL

1.1 DISPOSAL

At the end of the machine's working life, or when it can no longer be repaired, ensure that it is disposed of according to national regulations.

Contact your local authority for details of collection schemes in your area.

In all circumstances:

- Do not dispose of power tools with domestic waste.
- Do not incinerate.
- Do not abandon in the environment.
- Do not dispose of WEEE* as unsorted municipal waste.



Waste Electrical & Electronic Equipment.

12. EXPLANATION OF SYMBOLS

12.1 EXPLANATION OF SYMBOLS



Wear eye and ear protection.



Read operators manual.



Do not use in the rain or leave outdoors while it is raining.




Keep bystanders away.



Keep hands away from moving parts.



Switch off and remove plug from mains before cleaning or maintenance.



Warning:

Do not start the leaf blower vac without mounting the two suction/blowing tubes!

NOTES

DRAPER

CONTACTS

DRAPER TOOLS LIMITED,

Hursley Road, Chandler's Ford, Eastleigh, Hampshire. SO53 1YF. U.K.

Helpline: (023) 8049 4344

- Sales Desk: (023) 8049 4333

- Internet: www.drapertools.com

E-mail: sales@drapertools.com

- **Sales Fax:** (023) 8049 4209

- **General Enquiries:** (023) 8026 6355

- Service/Warranty Repair Agent

For aftersales servicing or warranty repairs, please contact the Draper Tools Helpline for details of an agent in your local area.

YOUR DRAPER STOCKIST

RDKC140515