



3 TONNE LEVER HOIST



82613 - LH3000C SPARE PARTS LISTING

KEY No.	PART No.	STOCK No.	DESCRIPTION
1	YLH3000C-1	01682	Nut
2	YLH3000C-2	01683	Hand Wheel
3	YLH3000C-3	01684	Screw
4	YLH3000C-4	01685	Washer
5-1	YLH3000C-5-1	01687	Lever handle
5-2	YLH3000C-5-2	01688	Selector
5-3	YLH3000C-5-3	01689	Washer
5-4	YLH3000C-5-4	06190	Pin
5-5	YLH3000C-5-5	01691	Bolt
5-6	YLH3000C-5-6	01692	Spring
6	YLH3000C-6	01693	Pawl
7	YLH3000C-7	01694	Shaft
8	YLH3000C-8	01695	Spring
9	YLH3000C-9	01696	Locking Plate
10-1	YLH3000C-10-1	01698	Locking Nut
10-2	YLH3000C-10-2	01699	Brake Seat
10-3	YLH3000C-10-3	01700	Washer
10-4	YLH3000C-10-4	01701	Spring
10-5	YLH3000C-10-5	01702	Clamp
10-6	YLH3000C-10-6	01703	Friction Disc
10-7	YLH3000C-10-7	01704	Ratchet Gear
10-8	YLH3000C-10-8	01705	Brake Seat
11	YLH3000C-11	01706	Nut
12	YLH3000C-12	01707	Brake Cover
13-1	YLH3000C-13-1	01709	Inner Cover
13-2	YLH3000C-13-2	01710	Bolt
14	YLH3000C-14	01711	Nut
15	YLH3000C-15	01712	Spring
16	YLH3000C-16	01713	Friction Disc
17	YLH3000C-17	01714	Ratchet Disc
18	YLH3000C-18	01715	Brake Seat
19	YLH3000C-19	01716	Washer
20	YLH3000C-20	01717	Pawl
21	YLH3000C-21	01718	Spring
22-1	YLH3000C-22-1	01720	Left Side Plate
22-2	YLH3000C-22-2	01721	Pin
23	YLH3000C-23	01722	Load Chain Cover
24	YLH3000C-24	01723	Needle Bearing
25	YLH3000C-25	01724	Load Sprocket
26	YLH3000C-26	01725	Stripper
27-1	YLH3000C-27-1	01727	Right Side Plate

KEY No.	PART No.	STOCK No.	DESCRIPTION
27-2	YLH3000C-27-2	01728	Steel Ring
27-3	YLH3000C-27-3	01729	Support Pin
28-1	YLH3000C-28-1	01731	Gear
28-2	YLH3000C-28-2	01732	Gear
29	YLH3000C-29	01733	Pinion Shaft
30	YLH3000C-30	01734	Splined Gear
31	YLH3000C-31	01735	Washer
32-1	YLH3000C-32-1	01737	Gear Cover
32-2	YLH3000C-32-2	01738	Steel Ring
32-3	YLH3000C-32-3	01739	Rivet
33	YLH3000C-33	01740	Top Hook Shaft
34-1	YLH3000C-34-1	01742	Top Hook
34-2	YLH3000C-34-2	01743	Pin
34-3	YLH3000C-34-3	01744	Nut
34-4	YLH3000C-34-4	01745	Spring
34-5	YLH3000C-34-5	01746	Safety Latch
34-6	YLH3000C-34-6	01747	Rivet
34-7	YLH3000C-34-7	01748	Top Hook Housing
34-8	YLH3000C-34-8	01749	Pin
34-9	YLH3000C-34-9	01750	Top Hook Housing A
34-10	YLH3000C-34-10	01751	Top Hook Housing B
34-11	YLH3000C-34-11	01752	Nut
35	YLH3000C-35	01753	Load Chain
36	YLH3000C-36	01754	Pin
37	YLH3000C-37	01755	Nut
38-1	YLH3000C-38-1	01757	Bottom Hook
38-2	YLH3000C-38-2	01758	Bottom Hook Housing
38-5	YLH3000C-38-5	07159	Screw
38-6	YLH3000C-38-6	01760	Pin
38-7	YLH3000C-38-7	01761	Axel
38-8	YLH3000C-38-8	01762	Axel
38-9	YLH3000C-38-9	01763	Nut
38-10	YLH3000C-38-10	01764	Rivet
39	YLH3000C-39	01765	End Anchor
40	YLH3000C-40	01766	Hand Grip
41	YLH3000C-41	01767	Nut
42	YLH3000C-42	01768	Screw
43	YLH3000C-43	01769	Pin
44	YLH3000C-44	01770	Nut
45	YLH3000C-45	01772	Nameplate
46	YLH3000C-46	01773	Rivet

3 TONNE LEVER HOIST

82613 - LH3000C SPARE PARTS LISTING

